

ACCESS CONTROL

USER MANUAL




CE FC RoHS 

System Components




Proximity and Keypad Reader



- 1 x Hex Key
- 4 x Plastic wall plug
- 4 x Countersunk screws
- 2 x Diode and 2 x Capacitor



Proximity and Keypad Reader



- 1 x Hex Key
- 4 x Plastic wall plug
- 4 x Countersunk screws
- 2 x Diode and 2 x Capacitor

Contents

Installation 4-5

Wiring Example 6

Advanced Programming Guide

 How to set-up Access Pin Number 6

 How to set-up Tags in **batches** 7-8

 Deleting Access Pin or Tag 8

 Changing Programming Pin 9

 Clear all Pin and Tag Data 9

 Default to Factory Settings 10

 Lock 1 Output Operating Time 10

 Enable 'Door Bell' Facility 11

 Enable 'Tamper Alarm' facility 12

 Access Pin Number for Lock 2 Output 12

 Deleting Access Pin for Lock 2 13

 Lock Output Operating Time for Lock 2 Output 13

System setup record 14-15


User Guide 16

Technical Specification 16

Installation




Release hex screw from the bottom of the keypad



(Side View)

Push the keypad up to release from mount plate




Thread system cable through the cable entry hole then make the system connections (as per the wiring diagram), mount the bracket to the surface and slide the keypad to the mountplate, re-fit the hex screw to secure into position.

Note: if using more than one keypad, ensure that the keypads are mounted a minimum 185cm apart

Installation




Release hex screw from the bottom of the keypad



(Side View)


Push the keypad up to release from mount plate




Thread system cable through the cable entry hole then make the system connections (as per the wiring diagram), mount the bracket to the surface and slide the keypad to the mountplate, re-fit the hex screw to secure into position.

Note: if using more than one keypad, ensure that the keypads are mounted a minimum 185cm apart


Wiring 1




Wiring 2



How to set-up Access Pin Number


Step Number	Action	Keypad Indication
1	Enter Programming 1 2 3 4 1 2 3 4 (Default)	 Long Tone
2	* 9	
3	0 2	 Long Tone
4	Enter a starting location number 0 0 0 ~ 9 9 9	 Double Tone
5	? ? ? ? Enter a 4 digit pin (1234 not be used)	 Long Tone
6	# # To end programming	

How to set-up Tags in batches (Normal EM125KHz cards)

Step Number	Action	Keypad Indication
1	Enter Programming 1 2 3 4 1 2 3 4 (Default)	 Long Tone
2	* 9	
3	0 1	 Long Tone
4	Enter a starting unused location number * 0 0 0 ~ 9 9 9	 Long Tone
5	? ? ? Enter 3-digit number as quantity of tags to be registered	 Tone
6	 Present all the tags one by one	 Tone
7	All tags will be auto register # # To end programming	



*Each tag will use up a location number (the locations must)

How to set-up Tags in batches (Tags in consecutive numbers)

Step Number	Action	Keypad Indication
1	Enter Programming 1 2 3 4 1 2 3 4 (Default)	 Long Tone
2	* 9	
3	0 5	 Long Tone
4	Enter a unused location number* 0 0 0 ~ 9 9 9	 Long Tone
5	? ? ? Enter 3-digit number as quantity of tags to be registered	 Tone
6	 Present the tag with the lowest serial number	 Tone
7	All other batch tags will auto register # # To end programming	

*Each tag will use up a location number

Deleting Access Pin or Tag

Step Number	Action	Keypad Indication
1	Enter Programming 1 2 3 4 1 2 3 4 (Default)	 Long Tone
2	Enter the location number of tag/pin 0 0 0 ~ 9 9 9	
3	* * To delete	
4	# # To end programming	

Changing Programming Pin

Step Number	Action	Keypad Indication
1	Enter Programming 12341234 (Default)	Long Tone
2	*3	
3	?? ?? Enter new 4 digit programming pin	
4	?? ?? Re-enter new 4 digit programming pin	Long Tone
5	# # To end programming	

Note; To access keypad's programming mode, the 4 digit programming code is entered in twice

If forgot the password, turn off the power, press and hold button


#

 , connect power again until Bi- sound is heard, the password will be reset to default one 1234.


Clear all Pin and Tag Data

Step Number	Action	Keypad Indication
1	Enter Programming 12341234 (Default)	Long Tone
2	*8	
3	88	Long Tone
4	# # To end programming	

Default to Factory Settings

Step Number	Action	Keypad Indication
1	Enter Programming 12341234 (Default)	 Long Tone
2	*8	
3	99	 Long Tone
4	# # To end programming	

Lock 1 Output Operating Time

Step Number	Action	Keypad Indication
1	Enter Programming 12341234 (Default)	 Long Tone
2	*1	
3	Enter number of seconds 00-99 ??	 Long Tone
4	# # To end programming	

Enable & Disable backlight

Step Number	Action	Keypad Indication
1	Enter Programming 	 Long Tone
2		
3	 To enable  To disable	 Long Tone
4	 To end programming	


 Default: Enabled the backlight

Enable 'Buzzer' Function

Step Number	Action	Keypad Indication
1	Enter Programming 	 Long Tone
2		
3	 To enable  To disable	
4	 To end programming	


*Once the "Buzzer" function is disabled, keypad operation becomes mute.

Enable 'Tamper Alarm' facility



Step Number	Action	Keypad Indication
1	Enter Programming 1 2 3 4 1 2 3 4 (Default)	 Long Tone
2	* 6	
3	0 2 To enable 0 1 To disable	 Long Tone
4	# # To end programming	

Tamper alarm activates the keypad's internal buzzer and 'door bell' output if the light sensor is exposed


Access Pin Number for Lock 2 Output

Step Number	Action	Keypad Indication
1	Enter Programming 1 2 3 4 1 2 3 4 (Default)	 Long Tone
2	* 9	
3	0 3	 Long Tone
4	Enter an unused location number 0 0 ~ 0 9	 Double Tone
5	? ? ? ? Enter a 4 digit pin (1234 should not be used)	 Long Tone
6	# # To end programming	

Deleting Access Pin for Lock 2

Step Number	Action	Keypad Indication
1	Enter Programming 12341234 (Default)	 Long Tone
2	*4	
3	Enter the location number of pin 00 ~ 09	
4	** To delete	
5	# # To end programming	

Lock Output Operating Time f or Lock 2 Output

Step Number	Action	Keypad Indication
1	Enter Programming 12341234 (Default)	 Long Tone
2	*5	
3	Enter number of seconds 00-99 ??	 Long Tone
4	# # To end programming	

To assist in future programming, it is recommended that a record is made of the system setup.

[illegible]

record is made of the system setup.

[illegible]

User Guide

To release Lock 1

(A)
Enter a programmed
Access Pin number



(B)
Present a
registered tag



To access programming mode

1 2 3 4 1 2 3 4
(Default)



Technical Specification

DC input	12 - 24volts
AC input	12 - 24volts
Standby current	80ma
Operating current (without lock)	110ma

Working temperature	-20c to +50c
Reader frequency	125KHz
IP rating	65
Dimension	150 x 44 x 24mm 119 x 76 x 21mm