
## Please read before attempting to install Magnetic Lock

## **MOUNTING INSTRUCTIONS**

Mount the armature plate on the door/gate using the rubber washer. The rubber washer and steel washer are installed between the armature plate and door, using the sex-nut bolt.





## **Typical Installation**

\*\*IMPORTANT\*\*: Do not install the armature plate too tightly, which ensures the washer remains flexible – in order for the armature plate to properly mate with the magnet.



